

# **KNOTWOOD**

IT'S NOT WOOD, IT'S ALUMINUM

## **Extrusion Manual**

### **Installation Guide and Section Profiles**

# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

<b>SLATS</b>	<b>4</b>
Profiles	5
<b>FENCING AND PRIVACY SCREENS</b>	<b>6</b>
Profiles	7
Installation	8
Horizontal Fence	8
Corner Fence Section	9
Horizontal Infill Install	10
Other Popular Styles	11
<b>GATES</b>	<b>12</b>
Profiles	13
Installation	14
Pedestrian Gate	14
Sliding Gate	15
<b>BALUSTRADE/RAILING</b>	<b>16</b>
Profiles	17
Installation	18
<b>DECKING</b>	<b>19</b>
Profiles	20
Installation	21
Interlocking Decking	21
Self-Mating Decking	22
<b>CLADDING</b>	<b>23</b>
Profiles	24
Installation	25
<b>BATTENS AND PERGOLAS</b>	<b>29</b>
Profiles	30
Installation	31
Architectural Battens	31
Pergolas	32

# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## WHITE SHADES



ASPEN



DRIFTWOOD



ASH



BEACH WOOD



ZEBIRANO

## BLACK SHADES



BLACK ASH

## YELLOW SHADES



IROKO



TASSIE OAK




LIGHT OAK



KNOTTY PINE




SPOTTED GUM



HICKORY



MAPLE



BLACKBUTT

## YELLOW SHADES



ATLANTIC  
CEDAR

## ORANGE SHADES




AUSTRALIAN  
CEDAR



RED GUM



KOA



TIGER WOOD



MERBAU



IRON BARK

## LIGHT BROWN SHADES



EASTERN  
MAHOGANY



WESTERN RED  
CEDAR



BUSH CHERRY



ELM



KWILA



TEAK BROWN

## Stock Colors

Colors with a grey background are the Knotwood stock colors.

## DARK BROWN SHADES



OLIVE TREE



BLACK WALNUT




WENGE

## RED SHADES



JARRAH



SYDNEY BLUE



ROSE  
MAHOGANY

All Knotwood woodgrain finishes come with a **Limited Lifetime Warranty**. Unlike natural wood, Knotwood will NEVER rot, warp or crack. With next to no maintenance, these finishes will look like new from the day they are installed, and never need to be painted, stained or oiled.

What more could you ask for?

[www.knotwood.com](http://www.knotwood.com)

1-855-566-8966



*\*Colors shown are indicative only, please call Knotwood for a production prepared sample for final color selection.*

# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## SLATS

Classic style or contemporary flair. Knotwood's range of slats are versatile and beautiful. Made from the highest grade of aluminum alloy, you can be assured of quality. Slats are the backbone of Knotwood's system. Strong and durable, they are designed to last.




# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## Profiles


All Slat profiles are 18' 6" lengths and can span up to 6' without support.  
Knotwood recommends you seek engineering in high wind or high traffic areas and refer to the Certified Fence Installation Guide (supplied on request).




**KES3816**  
38mm (1 1/2" Slat)  
**STOCK**



**KES6516**  
65mm (2 1/2" Slat)  
**STOCK**



**KES10016**  
100mm (4" Slat)  
**STOCK**



**KES15016**  
150mm (6" Slat)  
**STOCK**



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## FENCING and PRIVACY SCREENS

Made from high-quality, marine grade aluminum and protected by an award winning, woodgrain, powder-coat finish, Knotwood fencing is the original and the best. A Knotwood fence can give you the strength of aluminum with the realistic warm-feel of timber. Choose one of our stunning styles or create your own look using our versatile system, it's totally up to you. Vertical, horizontal, framed or picket, spacing big or small, wide or narrow, tall or short, you can take total control of your project to get the fence you really want.




# KNOTWOOD


IT'S NOT WOOD, IT'S ALUMINUM

## Profiles


All Posts are supplied in 18' 6" lengths. Other lengths can be ordered on request and are subject to the terms and conditions of Knotwood special orders. Maximum spans vary depending on installation and application. Knotwood advises proper consultation before recommending the system for a particular application.




**KESP2C5050 - 50 x 50**  
(2 x 2" Corner Post)  
**NON-STOCK**



**KESP2W5050 - 50 x 50**  
(2 x 2" Two-Way Post)  
**NON-STOCK**




**KESP1W5025 - 50 x 25**  
(2x1" One-Way Post)  
**NON-STOCK**



**KESP2C6565EF - 65 x 65**  
(2-9/16" x 2-9/16" Corner Post)  
**STOCK**



**KESP2W6565 - 65 x 65**  
(2-9/16" x 2-9/16" Two-Way Post)  
**STOCK**



**KESP1W6525 - 65 x 25**  
(2-9/16" x 1" One-Way/Top Rail)  
**STOCK**



**KESP3030 - 30 x 30**  
(1-1/8" x 1-1/8" U-Channel)  
**STOCK**

# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## INSTALLATION

Knotwood's fencing system is designed to be easily installed for a variety of finished products. The following are suggestions on the most commonly used designs. Anything is possible with a little ingenuity.

### Horizontal Fence



1. Concrete post (KESP2W6565) into ground.  
(Check with local building code for depth)
2. Install slats and spacers
3. Continue until complete.
4. Screw slats to post (KESP2W6565).
5. Clip on infill strips (KESINFS).
6. Install end caps (KAEC6565-R).
7. Repeat on all posts.
8. Install two (2x) infill strips to finish post (KESP2W6565).





# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## Corner Fence Section



1. Measure and cut post (KESP2C6565EF) to suit.
2. Attach base plate (KAOPBP65) to post (KESP2C6565EF).
3. Fix baseplate to the ground.
4. Install slats and spacers.
5. Screw slats to post (KESP2C6565EF).
6. Clip on infill strips (KESINFS).
7. Insert end caps (KAEC6565-R).
8. Repeat steps 5 to 7 on all posts.



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## Horizontal Infill Install



1. Measure and cut U-Channel (KESP3030) and SM Infill (KESINFS).
2. Screw U-Channel (KESP3030) to wall post or pillar.
3. Install slats and spacers
4. Screw slats to U-Channel (KESP3030).
5. Clip on infill strips (KESINFS).
6. Insert end caps.



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## Other Popular Styles



Santiago Style



Horizontal: No Gaps



Vertical: No Gaps



Vertical: Small Gaps



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## GATES

With the winning combination of strength, low maintenance and versatile range of styles, it's no wonder people the world over are using Knotwood's Gate system to elevate their homes to the next level.

Made from highly durable aluminum to look just like natural wood, you can have the beauty of timber without the associated problems. Front entry gates, pedestrian gates, driveway gates or even a barn door are all possible with the Knotwood Gate System. Choose from sliding or hinged opening options.

You can design your gate from scratch or select from our range of styles.





# KNOTWOOD


IT'S NOT WOOD, IT'S ALUMINUM

## Profiles




**KESGF10050** - 100 x 50  
(4 x 2" Large Gate Frame)

**STOCK**



**KESGF6640** - 66 x 40  
(2-1/2" x 1-1/2" Small Gate Frame)

**STOCK**




**KAGCSGFL**  
Large Gate Frame Corner Stake

**STOCK**



**KAGCSGFS**  
Small Gate Frame Corner Stake

**STOCK**



**KESGT80** - 80mm  
(3-1/8" Sliding Gate Track - MILL FINISH ONLY)


**STOCK**

# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## INSTALLATION

### Pedestrian Gate




1. Cut gate frame (KESGF6640).
2. Mitre gate frame (KESGF6640) corners 45 degrees.
3. Insert corner stake (KAGCSGFS).
4. Connect gate frame with corner stake (KAGCSGFS) and fix to gate frame (KAGSGF6640).
5. Install slats.
6. Attach top gate frame (KESGF6640) profile.
7. Screw slats to gate frame (KESGF6640).
8. Clip on infill (KESINFS).
9. Attach hinges (KASH).
10. Attach post (KEGS6565) to wall. NOTE: drill pilot hole.
11. Insert end caps (KAEC6565-R).
12. Attach hinges (KASH) to post.



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## Sliding Gate



- ① KESG100100
- ② KESGF10050
- ③ KES10016
- ④ #10-16 HEX SCREWS
- ⑤ KESINFS
- ⑥ KAEC100100-R
- ⑦ KAGCSGFL
- ⑧ SMALL SCREWS
- ⑨ KESP2W5050
- ⑩ KESINFS
- ⑪ KASP08 (8mm Spacer)  
KASP16 (16mm Spacer)  
KASP24 (24mm Spacer)
- ⑫ KAGSGTRB
- ⑬ KAGSGBW
- ⑭ KESGT80
- ⑮ KAGSGGS

1. Cut gate frame (KESGF10050).
2. Mitre gate frame (KESGF10050) corners 45 degrees.
3. Insert corner stake (KAGCSGFL).
4. Connect gate frame with corner stake (KAGCSGFL) & fix to gate frame (KESGF10050).
5. Measure and cut posts (KESP2W5050) to suit design.
6. Install slats to secure posts (KESP2W5050) to gate frame (KESGF10050).
7. Install Slats.
8. Attach top gate frame (KESGF10050) profile.
9. Screw slats to gate frame (KESGF10050) .
10. Attach gate track (KESGT80) to ground using either bolts or concrete.
11. Fix sliding gate pack (KAGSGP) components (KAGSGTRB, KAGSGBW, KAGSGGS) to post or wall.
12. Clip on infill (KESINFS).





# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## BALUSTRADE / RAILING

Certified and ready to roll, Knotwood's Balustrade/Railing system is an eye-catching and safe alternative to traditional balustrade. The strength of Knotwood's engineered aluminum sections really shine through to provide comfort, safety and luxurious good looks all at the same time.

Knotwood's balustrade supports all available Slats and Glass infill panels.







# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM


## Profiles




**KESP1W6525 - 65 x 25**  
(2-9/16" x 1" One Way Post/Top Rail)  
**STOCK**




**KESBF - 75mm (A)**  
(1" Handrail Base Clip)  
**STOCK**




**KESP2W6565 - 65 x 65**  
(2-9/16" x 2-9/16" Two Way Post)  
**STOCK**



**KESBTFR - 75mm (B)**  
(1" Handrail Clip Rectangular)  
**STOCK**



**KESP2C6565EF - 65 x 65**  
(2-9/16" x 2-9/16" Corner Post)  
**STOCK**



**KESBTFO - 75mm (B)**  
(1" Oval Handrail Clip)  
**STOCK**


Knotwood's range of railing/balustrade posts are supplied in 18'6" lengths. Infill panels can be made from the full range of Knotwood Slats or Glass panels.

# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## INSTALLATION

Guide only. Refer to Certification documents at [knotwood.com/downloads](http://knotwood.com/downloads) for full details.



- ① KESP1W6525
- ② KESP2W6565
- ③ KES10016
- ④ KESINFS
- ⑤ KASP08 (8mm Spacer)  
KASP16 (16mm Spacer)  
KASP24 (24mm Spacer)
- ⑥ SCREWS
- ⑦ CORING OR BASE  
PLATE (KAOPBP65-10)

1. Core drill posts (KESP1W6525/KESP2W6565) into concrete.
2. Screw slats (KES10016) to either side of posts.
3. Screw (KESP1W6525) to slats at the bottom.
4. Install remaining slats and secure to bottom rail.
5. Screw (KESP1W6525) to slats at the top.
6. Clip on infill strips (KESINFS).

**See our video section at [knotwood.com](http://knotwood.com)  
for installation videos and more.**




# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## DECKING

You'll know your decking is safe because it's made from high-quality marine grade aluminum and can't rust, rot or crack. It has a durable finish backed by a limited lifetime warranty, so you don't have to worry about it fading, chipping or going chalky. The deck doesn't require expensive and time-consuming maintenance.






# KNOTWOOD


IT'S NOT WOOD, IT'S ALUMINUM

## Profiles

All profiles come in 18' 6" lengths in any available Knotwood or powder-coat finish. Any seams made should be made at the joists. Profiles are designed for 16" joist centers. Always consult the appropriate building codes when designing or constructing substructures.



**KESM6516 - 65 x 16**  
(2-1/2" x 5/8" Self-Mating Slat)  
**NON-STOCK**




**KESM10016 - 100 x 16**  
(4" x 5/8" Self-Mating Slat)  
**NON-STOCK**



**KESM15016 - 150 x 16**  
(6" x 5/8" Self-Mating Slat)  
**STOCK**




**KED150 - 150 x 16**  
(6" x 5/8" Interlocking Decking/Cladding)  
**STOCK**



**KESTRADJ - 18' 6"**  
(Decking/Cladding Starter Strip)  
**STOCK**



**KESINFS - 18' 6"**  
(Small Infill Strip)  
**STOCK**



**KEDFA5050 - 18' 6"**  
(Decking/Cladding Concealed Finish Angle)  
**STOCK**




# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## INSTALLATION

### Interlocking Decking




1. Screw decking starter (KESTRADJ) to joists. NOTE: 16" centers.
2. Install decking board (KED100 / KED150).
3. Screw to joists.
4. Repeat until complete.
5. Mitre decking finishing angle (KEDFA5050) 45 degrees.
6. Screw to decking boards.
7. Clip infill (KESINFS) into finishing angle channel (KEDFA5050)



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## Self-Mating Decking



1. Cut and position self-mating slat (KESM15016).
2. Screw self-mating slat to joists (KESM15016).
3. Attach top self-mating slat (KESM15016).
4. Insert end cap(s) (KAEC15016-R).
5. Allow a few mm for expansion.
6. Repeat steps 1 to 4.

# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## CLADDING

Coated in Knotwood's award winning woodgrain finish, our cladding meets the highest finishing standards in the world. Backed by an industry leading limited lifetime warranty you can be sure that Knotwood cladding won't let you down. The unique hidden fastener system creates a clean finish that hides any unsightly screws or rivets. The interlocking system makes Knotwood cladding a smart choice when water penetration is a concern. Knotwood cladding requires next to no maintenance providing the benefits of wood without the drawbacks.





# KNOTWOOD


IT'S NOT WOOD, IT'S ALUMINUM

## Profiles


Cladding comes in 18' 6" lengths in any available Knotwood or powder-coat finish. Accessories come in 18' 6" lengths. Always consult the appropriate building codes when designing/constructing substructures.



**KED100S** - 4" x 5/8"  
(Decking/Cladding Board)  
**NON-STOCK**



**KED150** - 150 x 16  
(6" x 5/8" Interlocking Decking/Cladding)  
**STOCK**



**KEDSTRADJ** - 18' 6"  
(Decking/Cladding Starter Strip)  
**STOCK**



**KECFBF** - 18' 6"  
(Decking/Cladding Female Flashing Base)  
**STOCK**



**KECFTTLM** - 18' 6"  
(Decking/Cladding Male Flashing Top Clip)  
**STOCK**



**KECFJBF** - 18' 6"  
(Decking/Cladding Female Joiner Base)  
**STOCK**



**KECTJM** - 18' 6"  
(Decking/Cladding Male Top Joiner)  
**STOCK**



**KECIECLM** - 18' 6"  
(Decking/Cladding Male Internal/External Corner)  
**STOCK**





**KECIECF** - 18' 6"  
(Decking/Cladding Female Internal/External Corner)  
**STOCK**



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## INSTALLATION



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM



- ① KECIECLM
- ② KECIECF
- ③ KED150
- ④ RAIN SCREEN (Per Spec)
- ⑤ BATTENS 6" Center (Per Spec)
- ⑥ KEDSTRADJ

\* Bottom up installation shown,  
top-down installation recommended

## Starter Piece



- ① KEDSTRADJ
- ② KED150

# KNOTWOOD


IT'S NOT WOOD, IT'S ALUMINUM



- ① KEDSTRADJ
- ② KED150

\* Bottom up installation shown,  
top-down installation recommended

## Inside Corner



- ① KECIECF
- ② KECIECLM
- ③ KED150



# KNOTWOOD


IT'S NOT WOOD, IT'S ALUMINUM

## Outside Corner



- ① KECIECF
- ② KECIECLM
- ③ KED150

## Finishing Pieces




- ① KECFTTLM
- ② KECFBF
- ③ KED150

# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## BATTENS AND PERGOLAS

Knotwood's Clip-Batten system is as revolutionary as it is eye-catching. A built-in bracket provides a unique floating look that hides unsightly bolts and provides a look you simply can't get anywhere else. Not only can you create stunning features, but the versatile system can be used to create an oasis in the form of a pergola or trellis.



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## Profiles

Clip-Batten Profiles are designed for spans of up to 18' 6" without a joint. Wind loads may vary in different regions. Consult an engineer if unsure about the systems viability for a specific application. Profiles come supplied in any available color in an 18' 6" standard length. Battens are 36" on center.



**KEB5050F - 50 x 50**  
(2" x 2" Batten Part B)  
**STOCK**



**KEB10050F - 50 x 100**  
(2" x 4" Batten Part B)  
**STOCK**




**KEB15050F - 50 x 150**  
(2" x 6" Batten Part B)  
**STOCK**



**KEB20050F - 50 x 200**  
(2" x 8" Batten Part B)  
**STOCK**



**KEB5050M - 50 x 50**  
(2" x 2" Batten Part A)  
**STOCK**



**KAEC5050-R** (2" x 2" Caps)  
**KAEC10050-R** (2" x 4" Caps)  
**KAEC15050-R** (2" x 6" Caps)  
**KAEC20050-R** (2" x 8" Caps)




# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## INSTALLATION

Any Part B can be used with the Part A Bracket. Installation Guides are for reference only.

### Architectural Battens



- ① KEB5050M
- ② KEB15050F
- ③ SCREWS
- ④ KAEC5050-R (2x2 Caps)  
KAEC10050-R (2x4 Caps)  
KAEC15050-R (2x6 Caps)  
KAEC20050-R (2x8 Caps)


1. Attach KEB5050M to wall.
2. Clip KEB15050F onto the KEB5050M.
3. Repeat until complete.



# KNOTWOOD

IT'S NOT WOOD, IT'S ALUMINUM

## Pergolas



1. Install posts into ground (KEGS100100).
2. Bolt rails (KEGR20050) to posts (KEGS100100).
3. Screw (KEB5050A) to (KEGR20050) to either side of the posts.
4. Clip (KEB15050F) to (KEB5050M) and secure to posts with bolts.
5. Secure the remainder of the (KEB5050M) to rails at the desired spacing.
6. Clip the (KEB15050F) onto (KEB5050M)
7. Screw end caps (KAEC15050-R/KAEC20050-R) to batten and rails.

